












# WHEEL CYLINDER LISTING

Ate Number	Vehicle Application	Bore Size	Photo
321400	VW Citi Golf 83-09, Fox 87-95, Golf/Jetta 1/2/3 78-99, Passat 78-85, Polo 96-02	14.46	
321500	Nissan Sabre/ Sentra 92-97	15.59	
321501	Mazda 323 1500 83-86	15.59	
321700	VW Citi Golf, Fox, Golf/Jetta 1/2/3 (Some), Passat, Polo 78-2010, Polo Vivo 2010- with ABS	17.46	
321702	Ford Laser/ Meteor 86-95; Mazda 323 86-02; Hyundai i20 (some) 2007-on; Kia Rio II/III Models (some) 2005-on	17.78	
321703	Opel Ascona, Astra, Kadett, Monza 81-96	17.46	
321705	Ford Courier; Mazda B Series 86-99 - <i>LHS</i>	17.46	
321706	Ford Courier; Mazda B Series 86-99 - <i>RHS</i>	17.46	
321707	Chev. Spark 1.0, 1.2 2010-on; Opel Ascona, Kadett, Monza 81-92	17.46	
<b><i>321709 NEW!</i></b>	Nissan NP200 (Some) 2008-on; Renault Clio I/II (Some) 99-06, Sandero (Some) 2008-on	17.46	
<b><i>321710 NEW!</i></b>	Chery QQ3 - All 2007-on; Chev. Spark - All 2003-2013; Daewoo Matiz - All 99-03	17.46	
<b><i>321712 NEW!</i></b>	Hyundai Accent - All 2000-2010, Atos (Some) 2004-2013, Getz - All 2004-2010, i10 (Some) 2007-2014, i20 (Some) 2008-; Kia Rio II/III (Some) 2005-	17.46	
<b><i>321713 NEW!</i></b>	VW Citi Golf (Some) 83-09, Golf/ Jetta 1/2/3 (Some) 78-97, Polo 97-02 (Some), Polo Vivo (Some) 2010-, up! 2014-on (Aluminium casting)	17.46	

# WHEEL CYLINDER LISTING

Ate Number	Vehicle Application	Bore Size	Photo
321900	Toyota Conquest, Corolla, Hi Lux 79-05	19.05	
321901	Chev. Aveo 03-08; Opel Astra, Corsa, Kadett 91-00, Opel Corsa LDV 03-06	19.05	
321902	Nissan 1200, 1400, B140 71-08	19.05	
321903	Ford Cortina, Escort 78-86, Fiesta (Some) 97-02; Nissan Langley, Pulsar 83-87	19.05	
321905	Fiat Seicento, Uno 90-05	19.05	
321906	VW Beetle 57-79 (Rear)	19.05	
321907	VW Polo 96-02 (Non ABS), Polo Vivo (Some) 2010-	19.05	
321908	BMW 316, 320i, 518i, 520i 82-89	19.05	
321910	Mazda 626 82-92	19.05	
321911	Nissan Sabre, Sentra 87-02, B140 Bakkie 93-08 - <i>LHS</i>	19.05	
321912	Nissan Sabre, Sentra 87-02, B140 Bakkie 93-08 - <i>RHS</i>	19.05	
321913	Toyota Hi Lux 4x4 79-92 - Imp. Diff	19.05	

# WHEEL CYLINDER LISTING

Ate Number	Vehicle Application	Bore Size	Photo
<b><u>321914 NEW!</u></b>	Chev. Corsa Utility LDV (Some) 05-2012; Ford Fiesta 02-08 - All models with Rr. Drums, Ikon - All - 01-06, KA (Some) 05-08; Mazda 121 Soho - all - 97-01; Nissan Micra (Some) 03-2011, Livina/ Tiida (Some) 07-2013; Opel Corsa D - All models with Rr. Drums 08-2015; Renault Clio 2/3 (Some) 03-09	19.05	
<b><u>321915 NEW!</u></b>	Ford Fiesta 2008-2012 - All models with Rr. Drums	19.05	
<b><u>321916 NEW!</u></b>	Toyota Etios 2012-on	19.05	
<b><u>321918 NEW!</u></b>	Nissan NP200 (Some) 2008-on; Renault Clio 1/2 (Some) 99-06, Logan, Sandero (Some) 2008-2012	19.05	
<b><u>321919L NEW!</u></b>	Toyota Yaris 1.0, 1.3 (Some) 2006-2012 - <i>LHS</i>	19.05	
<b><u>321919R NEW!</u></b>	Toyota Yaris 1.0, 1.3 (Some) 2006-2012 - <i>RHS</i>	19.05	
322000	Ford Cortina MkV 80-83, Escort MkV 95-99, Focus II 1.6 05-09, Granada 78-86, Mondeo 96-04, Sapphire/ Sierra 83-89, Bantam 02-2017; Mazda 323 85-89; Nissan 1800, 720, E20 73-83	20.64	
322001	Toyota Camry 200 92-97	20.64	
322003	BMW 316, 320, 520 83-87	20.64	
322004	Toyota Hi Lux 4x4 79-92 - Imp. Diff	20.64	
<b><u>322005L NEW!</u></b>	Toyota Yaris 1.0, 1.3 (Some) 2006-2012 - <i>LHS</i>	20.64	
<b><u>322005R NEW!</u></b>	Toyota Yaris 1.0, 1.3 (Some) 2006-2012 - <i>RHS</i>	20.64	

# WHEEL CYLINDER LISTING

Ate Number	Vehicle Application	Bore Size	Photo
322200	CAM Inyathi (Some) 2007-; Toyota Corolla, Cressida, Stallion, Venture 78-92	22.22	
322201	Ford Focus I 00-05, Bantam 94-2013; Mazda Rustler 86-02; Mitsubishi Colt LDV (Some) 94-08	22.22	
322202	VW Beetle 57-79 (Front)	22.22	
<b><u>322203</u></b> <i>NEW!</i>	Toyota Hi-Lux, Fortuner (Some) 2005-2016	22.22	
322205	BMW 316, 320 88-92	22.22	
322207	Toyota Cressida 78-92	22.22	
<b><u>322208</u></b> <i>NEW!</i>	Chev. Corsa Utility LDV (Some) 2010-on; Opel Comm. Corsa P/van, Combo P/van 1999-2012, Corsa Utility LDV (Some) 1997-2010	22.22	
<b><u>322209</u></b> <i>NEW!</i>	Nissan NP200 (Some) 2008-on; Renault Logan (Some) 2008-2012	22.22	
322300	Ford Cortina, Husky 85-99; Isuzu KB Series 81-96; Mazda B Series 86-99; Mitsubishi Colt LDV (Some) 94-08, L300 85-99; Toyota Hi Ace, HiLux 79-87	23.81	
322301	VW Kombi 71-02	23.81	
322302	BMW 316 92-99	23.81	
<b><u>322303</u></b> <i>NEW!</i>	Toyota Hi-Lux, Fortuner (Some) 2005-2016; Quantum 2005-2016 (Some)	23.81	

# WHEEL CYLINDER LISTING

Ate Number	Vehicle Application	Bore Size	Photo
322304	CAM Inyathi (Some) & Rhino 2006-	23.81	
<b><u>322306 NEW!</u></b>	Isuzu 04-2013 KB200/240/250/300/ 350/ 360 - LE, LX, Fleetside, D-Max & D-Tec Models	23.81	
322500	Isuzu KB Series 91-96; ; Mitsubishi Colt LDV (Some) 94-08; Nissan 720, 1 Tonner, Hardbody, E20, Sani 73-99	25.40	
322505	Toyota Quantum (Some Models) 2005-2012	22.22	
<b><u>322700 NEW!</u></b>	VW Amarok 2.0TDi, BiTDi 2010-on	27.00	